

# MY BEAUTIFUL MINI

## Fitting Instructions for Interior Chrome Pieces bought separately from full interior kits

### ABS CHROME INTERIOR CHROME ACCESSORIES

#### CARE OF YOUR CHROME

Like chrome on metal, ABS benefits from wiping with a damp cloth, to remove any dust or grease we then recommend and polishing with a soft duster.

Installing our ABS Chrome Accessories, quick easy and can be done in minutes. All you have to do is follow the instructions.

#### Step 1

Check the fit and alignment

Carefully check the fit of each piece to assure proper fit and alignment of each part. **DO NOT REMOVE FILM FROM THE BACKING TAPE AT THIS STAGE!** Some of pieces are marked LEFT and RIGHT to ensure you have the correct side. Some also have arrows which indicate UP or DOWN this is to ensure you have the piece in the correct position.

#### Step 2

Clean surface thoroughly

Clean the surface to which the piece is to be fitted and ensure that all the dust, grease and other contaminants etc, is removed. **THE SURFACE MUST BE PERFECTLY DRY AND FREE OF ANY OILS OR OTHER CONTAMINANTS** for the piece/ kit to adhere properly!

#### Step 3

Apply adhesion promoter

Carefully apply adhesion promoter. use the alcohol pad (if provided), **ONLY TO AREAS TO BE COVERED WITH CHROME OVERLAY/SURROUND!** Allow to fully dry before continuing.

#### Step 4

Remove the film from the 3M backing tape, align the item and hold in place applying light pressure for approximately 30 seconds. **YOU ARE NOW FINISHED.**